



E8X Carbon Fiber Rear Diffuser

The Carbon Fiber Rear Diffuser is part of the BMW Performance line. Installation is simple and takes less than 10 minutes.

Tools Required:

- 8mm Socket and Wrench
- cloth/towel

Begin the installation by placing the towel over the exhaust tips (make sure the car is cooled down). This is just a preventative step to insure you do not scratch the stock diffuser or the carbon diffuser.



Along the bottom edge of the diffuser are 6 8mm screws. remove the screws and set them to the side.



Once the screws have been removed, the diffuser will stay in place. There are 11 clips along the top edge that clip into the bumper. With a clean finger press against the bumper just above where you are pulling to release the clip. Begin at one side and work your way to the other. If you have access to a second set of hands, you may want them to help hold the diffuser as you go.

Here is a picture of the stock diffuser. I tried to do a close up of one of the clips.



With the stock diffuser removed, you can install the Carbon Fiber Diffuser. Installation is the reverse of removal. Begin by positioning the diffuser and docking the clips. Once the diffuser is clipped in place, install the 8mm screws. The stock diffuser has 6 screws, the Carbon Diffuser has 5 so you will have one extra.

I will post more pictures later today.



